

Monthly Maintenance Newsletter



Peacock Salt

Saturator Pump

The pump is a key component of any saturator. To ensure your pump is working at its optimum, there are a few key points to maintain:

- Ensure you keep the basket filter clean from any debris.
- Keep the base of the saturator clean from sludge. If you have an Ecosol it is good practice to clean the base out frequently.
- Keep your Ecosol lid in position – this will prevent any ingress of debris or rainwater.
- Make sure your pump is secure to its base-plate.
- Clean off any debris or accumulated salt from the motor cowling (filter housing at the end of the motor) and the frame of the pump (the vanes especially). This ensures your pump & motor is kept cool when circulating the brine.
- Ensure any associated pipework leaks are repaired as a matter of urgency.

Clean filter basket



Motor vanes need cleaned



Bad leak at valve, potential pump problems



Tank not cleaned, pump failed





Serviced Pump Station



Download Pump Manual