

Monthly Maintenance Newsletter



Peacock Salt

Stir Tank Contents

During the winter months we can often have a period of mild weather. During this time its best practice to put the system into stir tank. This will protect your pump and keep the system ready for when you need it next

Process

1. If using manual system rotate valve to stir tank setting
2. Select position 3 on selector switch
3. Auto system will rotate valves to correct position
4. Pump will now operate and pump brine around system
5. Leave switch on this setting during your mild period and the saturator will automatically stir the tank every 48hours for 30 mins.
6. If expectation of cold weather please select position 1



Common Faults

1. Flow rate around pump very poor?
 - a. Check filter basket is empty
 - b. Check ball check valve is not blocked

- c. Prime pump with fresh water through priming cap



Download Training & Operating Manual